

microflex®

988 System Agent SCR

System agent for regular use in SCR catalyst systems. This specially developed formulation reliably cleans crystal formation from urea dosing systems and SCR catalytic converters. This can prevent power losses or motor malfunctions.



Properties

- ✓ Protects urea dosing systems and SCR catalysts from crystal formation
- ✓ Cleans urea dosing systems and SCR catalysts with limited performance due to crystal formation
- ✓ Reduces foaming
- ✓ Suitable for use by the end customer
- ✓ Easy to dose

Application area

- ✓ For use with crystal formation in urea dosing systems and SCR catalysts

Instructions

Squeeze the dispenser bottle to fill the dosing area of the bottle with the necessary amount of active ingredient. Add the measured quantity to the canister/bottle containing the urea solution. Then add the mixture to the urea tank. Add the system agent regularly, at least every time the urea tank is filled.

Dosing

For measuring the dosage, see the scale on the dosing area of the bottle.
One bottle of SCR System Active Substance (250 ml) is enough for 100 litres of urea fluid.

Notice

- ✓ Caution! In systems where the urea injection is supported by air pressure, increased foaming may occur.

Product Description	Contents	Article Number	Packaging Unit
System Agent SCR	250 ml	1106122	12 PCS

