

microflex®

## 923 SCR Special Cleaner

Special cleaner for crystalline deposits in SCR systems.



### Properties

- ✓ Cleans urea dosing systems, injectors and SCR catalysts with limited performance due to crystal formation.
- ✓ The probe makes it easy to access hard-to-reach parts.

### Application area

- ✓ For use in the event of crystal formation in urea dosing systems and SCR catalytic converters. This occurs when the required temperatures for complete transformation into ammonia are not reached.

### Instructions

Remove the parts to be cleaned if required and spray liberally. Allow the product to take effect for several minutes and dry with compressed air if required.

### Notice

- ✓ To prevent the crystals forming again, we recommend using Additive 987 on a regular basis.

Product Description	Contents	Article Number	Packaging Unit
SCR Special Cleaner	300 ml	1107162	12 PCS

