

microflex® 923 SCR Special Cleaner

Special cleaner for crystalline deposits in SCR systems.



Properties

- ✓ Cleans urea dosing systems, injectors and SCR catalysts with limited performance due to crystal formation.
- ✓ The probe makes it easy to access hard-to-reach parts.

Application area

- ✓ For use in the event of crystal formation in urea dosing systems and SCR catalytic converters. This occurs when the required temperatures for complete transformation into ammonia are not reached.

Instructions

Remove the parts to be cleaned if required and spray liberally. Allow the product to take effect for several minutes and dry with compressed air if required.

Notice

- ✓ To prevent the crystals forming again, we recommend using Additive 987 on a regular basis.

Product Description	Contents	Article Number	Packaging Unit
SCR Special Cleaner	300 ml	1107162	12 PCS

